

Mifare[®] Card Issuer

PCR310/PCR320 programmer for

MF700/LBR700 Reader

User's Manual

REV.I

December 29, 2009

Table of Contents

Table of Contents	2
Understand the MAD and Non-MAD	3
Connect the PCR310U programmer	5
Issue Data into Non-MAD or MAD card	6
To issue a Wiegand Format card , example as below:	7
To issue a User-Data card , example as below:	9
To issue a "Card Holder Information" card , example as below	10
To Import users from file	11
Create and Manage your MAD card	13
1. [Format] to create your MAD cards and include your AID.....	13
2. [Assignment] your customer AID into your MAD card.....	14
3. [Remove AID] from your MAD card.....	14
ANNEX A. Issue Card flow chart	15
ANNEX B. Without Card Holder Information Format	16
ANNEX C. DESFire/EV1 Card Issuing(for PCR320)	17
ANNEX D. History	18

Understand the MAD and Non-MAD

Before you operate Mifare Card Issuer (Programmer), you have to know something about MAD and Non-MAD.

MAD Format Card			Non-MAD Format Card			
MAD	Block 0	Manufacturer Code	Sector 0	Block 0	Manufacturer Code	
Sector (0)	Block 1	MAD	Other User Data	Block 1	Sector Security	
	Block 2	AID(n)		Block 2		
	Block 3	Sector Security		Block 3		
.			.			
.			.			
.			.			
Application	Block 0	User Data	Application	Block 0	User Data	
Sector (n)	Block 1		Sector Security	Sector		Block 1
	Block 2			(fixed)		Block 2
	Block 3	Sector Security		Block 3	Sector Security	

When using MAD application, Mifare Application Directory (MAD) is stored at sector 0 for Mifare Standard 1K card (or at sector 0 and sector 16 for Mifare standard 4K card) According to MAD, get AID and its mating Application Sector number. When using Non-MAD application, the parameter of Non-MAD Sector number will directly lead the Application Sector Number.

Card Security will be update as below after issued card:


MAD Sector	Block 0	Manufacturer Code
Sector (0)	Block 1	MAD
	Block 2	AID
	Block 3	KEY_A ¹ is Read Only, MAD Admin Key ² is Read/Write (KEY_B)
.		
.		
Application	Block 0	User Data
Sector (n)	Block 1	
	Block 2	
	Block 3	

1. KEY_A = A0A1A2A3A4A5, this is the fixed KEY of MAD, it can be used for read only.
2. MAD Admin Key is the key for the MAD card issuer to manage MAD card. It can be used for Read and Write.
3. App Key is the key for the MF700/LBR700 reader to read the data or Application Sector. It can be used for Read only..
4. App Admin Key is the key for the Application manager to issue the card and write data into the card. It can be used for Read and Write.

Configure the Parameters of MF700/LBR700 Card Issue

According to MAD or Non-MAD application, you have to set the Card Issuer parameters before issuing the card.

Click [Configure] to begin settings the parameters: (Example as below)



1. **MAD Admin Key** (Default=FFFFFFFFFFFF, KEY_B):

The key is for the Administrator to plan the MAD application and it can assign the AID and its mating Sector number.

2. **MAD-AID** (Hex, Default=4703):

If you have application AID from Mifare MAD group, you may set this AID number into MAD-AID to become the identifier of your application. (or you may assign AID number by yourself for your

application if you did not apply AID from Mifare MAD Group.). The default 4703 is AID for Access Control & Security application of GIGA-TMS INC.

3. **Non-MAD Sector#** (Default=1)

For the Non-MAD application, you have to set Non-MAD Sector number. By means of this setting, the User-Data is written into the Sector of the set Non-MAD Sector number. MF700/LBR700 Reader only can read the data on the set Non-MAD sector if the card is Non-MAD format.

4. **App Admin Key** (Default=FFFFFFFFFFFF, KEY_B):

The key is used for managing the data in the Application Sector. It can be used for Reading and Writing the data.

5. **App Key** (Default=FFFFFFFFFFFF, KEY_A)

The key can only read the data. MF700/LBR700/DF700 Reader is using the App Key to authenticate with the card.

6. **Max App Sectors** (Default=1) for multi sectors in use.

7. **Password** (Default=Blank)

The Mifare Card Issuer software is with Logon Password protection. If you set with password, you have to enter Password every time when you execute the Mifare Card Issuer.

8. **Encrypt (Default=None)**

Fraud prevention, Select Encrypt Mode (None, Encrypt 1, Encrypt 2, Encrypt 3, Encrypt 4, Encrypt 5) to protected your card data. (Remark: Encrypt mode must to work together with the same encrypt mode of MF700/LBR700 configure utility.)

Remark:

When you exit the Mifare Card Issuer software, it would automatically store all these keys and parameters you have set. However, these keys might be lost if the computer is broken. So you must well keep all these keys to avoid any problem when the computer is broken.


Connect the PCR310U programmer

Prepare for issuing the card, you have to connect the PCR310 programmer to the computer through USB port. If this is your first time to use PCR310 Programmer for you computer, you need to install USB Driver for PCR310. Get the DISK5219 USB driver and put into CD-ROM drive to install it. Just follow the on-screen instructions. After USB driver is installed, click [AutoScan] on Mifare[®] Card Issuer software, it would find and get PCR310 programmer connection with it.

Issue Data into Non-MAD or MAD card


Mifare Card Issuer provides three kinds of data formats to write the card: Wiegand, User-Data and Card Holder Information. The way to write data into MAD card or Non-MAD card is the same. (Refer to ANNEX. A). If you want to issue a MAD card, you must format the card first and then issue the card. (Please first refer to the Paragraph of Create and Manage your MAD card).

Put a new (or two) card (MAD or Non-MAD) into PCR310 programmer, example as below:



1. Card CB4623C2 is a Mifare Standard 1K card, and card type is Non-MAD format, the App Sector is writeable.
2. Card CB46D7C2 is a Mifare Standard 1K card, and card type is MAD format, the App Sector is writeable.

To issue a Wiegand Format card , example as below:

<p>Step 1:</p> <p>Select the Card CB4451582 for example (if you put two cards on PCR310 programmer). Click [Issue Card] to write sector data.</p>	
<p>Step 2:</p> <p>Select [Wiegand Format]</p> <p>Note:</p> <p>You also can configure your "Bit Size" for "System Code", "Site Code" and "Serial Number" fields.</p>	
<p>Step 3:</p> <p>Input System Code, Site Code and Serial Number in the Wiegand Fields.</p>	 <p>The screenshot shows a software window titled "Issue Card - F77A8BE2". It has two tabs: "Wiegand / TK2" (selected) and "User Data". Under "Wiegand / TK2", there are three rows of fields: "System Code" with value "1" and "Bit Size" set to "16"; "Site Code" with value "1" and "Bit Size" set to "8"; and "Serial Number" with value "0" and "Bit Size" set to "16". There is a checkbox for "Auto Step for Serial Number" which is unchecked, with a value of "1" next to it. Below this is a section for "Card Holder Information (Optional)" with fields for "Surname", "Given Name", and "Sex" (set to "None"). At the bottom, there is a "Remain capacity" progress bar at 85% and four buttons: "Import", "Read Card", "Write Card", and "Close". A green "Ready OK" message is visible at the very bottom of the window.</p>
<p>Step 4:</p> <p>Click [Write] to write all Wiegand Fields into Card.</p>	

Note:

1. Auto Step: Automatically step the number. If this function is Enabled, it will step the number with the set step value for the sequential number. This function is only for the "Serial Number" field.
2. Wiegand Format as below: (Max 16 bytes for Wiegand Format)


Fields	Bit Size	Memory Order
System Code	8~42	3 (MSB)
Site Code	8~42	2
Serial Number	8~42	1 (LSB)

Remark: The MF700/LBR700 reader will read number of data size by "Number Of Bits" set.

Example for Wiegand 44bits (Standard Bits Sequence and "Serial Number" bit size=18):

Parity Bit	System Code		Site Code		Serial Number		Parity Bit
Even	b16	b1	b8	b1	b18	b1	Odd
b44 (Even)			b23	b22 (Odd)			b1

To issue a User-Data card , example as below:

<p>Step1: Click [Issue Card] and select [User Data] button.</p>	
<p>Step 2: Input Hex Code in "Hex Code Edit" or Input ASCII string in "ASCII String Edit".</p>	
<p>Step 3: Click [Write Card] to write user data into the card.</p>	


Note:

1. In User Data format, customer can write HEX Code or ASCII String into the card, and the user data can be defined by customer himself.
2. Click "Use CSN" will input the card serial number to ASCII String Edit box.

Remark:

You may set the "Max App Sectors" in "Configure", to get more sectors for data size.

To issue a "Card Holder Information" card , example as below

<p>Step 1: Move cursor to "Card Holder Information" fields.</p>	
<p>Step 2: Input Surname, Given Name, Sex and User Data</p>	
<p>Step 3: Click [Write Card] to write user data into the card.</p>	

Note:


"Card Holder Information" format is defined by MAD, and use ASCII String data for each fields.
The total data length for all the 4 fields (Surname, Given Name, Sex and User Data) is 46 ASCII characters maximum.

Remark:

- 1. You may set the "Max App Sectors" in "Configure", to get more sectors for data size.**
- 2. Set up "Pass Code for" LBR700 Reader and max 8 digits.**


To Import users from file

Step 1:
Click "Import"




Step 2:
Select user list file.


Example:
Select "sample data 2.txt"




Step 3:
Enable "Field name in first row", if first row are field name.




Step 4:
Redefine field name



Step 5:
Click "OK" when fields define finished.



Step 6:
Select user, and the user will assign to corresponding fields.



Remark:
Support file format: Text , CSV, Excel (Need Microsoft® Excel installed first)

Create and Manage your MAD card


If you are issuing MAD card, you may use "Format", "Assignment" and "Remove AID" to create and manage your MAD card.

1. **[Format]** to create your MAD cards and include your AID.

You may format all new cards with MAD Format first. After formatted, all the sectors on the card will be protected with MAD Admin KEY (KEY_B). If you have set AID when you configure to set the Mifare Card Issuer parameters, it would write AID into MAD Sector when you format the cards, and it would automatically mate AID to Sector #1 and the Sector #1 would be protected with App Key (KEY_A : Read Only) and App Admin Key (KEY_B: Read/Write).

Note: If Sector#1 has been used with other Application, It would mate AID to Sector#2 or other free sector when the card is formatted.


To format a Non-MAD card to a MAD format card , for example as below (AID=1234):



2. [Assignment] your customer AID into your MAD card.

You may also put the Customer AID into your MAD card and you may assign the Customer AID to use the Customer Sector#. And let the Customer Sector# be protected with Customer Admin Key (KEY_B: Read / Write, Default=FFFFFFFFFFFF).


For example, to Assignment the AID=5678 to Sector 2 with KEY=B0B1B2B3B4B5 (KEY_B) protected as below:



3. [Remove AID] from your MAD card..


You may also to remove the issued AID from your MAD card. The AID pointer sector will be free and protected with MAD Admin Key after the AID be removed.

For Example, to remove the AID=5687 from your MAD card.



Remark: The customer Admin Key must be set in "Customer Admin Key" field, to free the AID pointer sector.

ANNEX A. Issue Card flow chart



ANNEX B. Without Card Holder Information Format

Storing card holder information using RLC (Run-Length-Coding)

bit7 bit0


byte n	byte n-1	byte 1	byte 0
00	last character		character 1	type length<n>

byte 0: **length** = lower 6 bit (number of used bytes including 0x00, max. 63)


type = highest 2 bit (**00**=surname; **01**=given name; **10**=sex; **11**=user data)

byte 1 to <n>: ASCII text as specified in **type** (first character at byte 1; ends with 0x00)

If you want to use raw data for the reader , please mark "Without Card Holder Information"




Setup configuration of the reader by "Mifare Reader Utility".



ANNEX C. DESFire/EV1 Card Issuing(for PCR320)

Configuration



DF Master Key:

(Default=00000000000000000000000000000000):

The key is for the Administrator to plan the DESFire Card and it can assign the AID and Format card.

DF App-AID: (Default=F47030):

If you have application AID from Mifare MAD group, you may set this AID number into DF App-AID to become the identifier of your application. (or you may assign AID number by yourself for your application if you did not apply AID from Mifare MAD Group.). The default F47030 is AID for Access Control & Security application of GIGA-TMS INC. (FID=0 for User Data).

DF App Admin Key (KeyNo = 0):

(Default=00000000000000000000000000000000):


The key is used for managing the data in the Application File.

It can be used for Reading and Writing the data.

DF App Key (KeyNo = 1): (Default=00000000000000000000000000000000):

The key can only read the data. MF700/LBR700/DF700 Reader is using the DF App Key to authenticate with the DESFire card.

Main



Application List:

List of all application in DESFire Card.

Format:

Assign two AID in DESFire Card. One is your application AID. The other one is Pass Code application(F4703F).

(REMARK: If the DF Master Key is not correct, you can not format the card.)

ANNEX D. History

June 15, 2004 REV.A

Initial Mifare® Card Issuer

June 29, 2004 REV.B

Support Multi Sectors (Page 3).

Support Configurable "Bit Size" for each fields of Wiegand format (Page 5,6).

April 25, 2005 REV.C

Add Encrypt mode for fraud prevention. (MF700)

November 30, 2005 REV.D

Add "Import" function. (Mifare Card Issue V1.1, Page 10)

November 28, 2007 REV.E

Add "Pass Code" function. (Mifare Card Issue V1.2, Page 9)

May 29, 2008 REV.F

Add "Use CSN" function. (Mifare Card Issue V1.1R4 Page 8)

November 21, 2008 REV.G

Add "Without Card Holder Information" function. (Mifare Card Issue V1.1R5, Page 16)

July 16, 2009 REV.H

Add " DESFire Card Issuing " (Mifare Card Issue V1.1R6, Page 17)

December 29, 2009 REV.I

Modify" DESFire/EV1 Card Issuing " (Mifare Card Issue V1.1R8, Page 17)

NOTE!!!

Hereby, GIGA-TMS INC., declares that the radio equipment type PCR310 / PCR320 is in compliance with Directive 2014/53/EU.

GIGA-TMS INC., Address: 8F, NO.31, LANE 169, KANG-NING ST., HIS-CHIH, NEW TAIPEI CITY, 22180 TAIWAN R.O.C.

The operating frequency bands and the maximum RF power (target power) transmitted in each band of PCR310 / PCR320 is following:

PCR310: 13.56MHz band -6.08 dBuA.

PCR320: 13.56MHz band -14.38 dBuA.

PROMAG[®]

GIGA-TMS INC.


<http://www.gigatms.com.tw>

<mailto:promag@gigatms.com.tw>

TEL : +886-2-26954214

FAX : +886-2-26954213

Office: 8F, No. 31, Lane 169, Kang-Ning St., Hsi-Chih, Taipei, Taiwan



Waste Electrical and Electronic Equipment (WEEE)

This symbol means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. Proper recycling of your product will protect human health and the environment.

TM951128B